

Limited Warranty Statements

1. Warranty

Lockey Digital Systems Inc. (hereafter "LDS") warrants the Product to be free from defects in material and workmanship for a period of 12 months from the original date of purchase.

If you discover a defect in the Product covered by this warranty, we will repair or replace the item at our option, using new or refurbished components.

2. Exclusions

This warranty covers defects in manufacturing discovered while using the Products as recommended by LDS rather than occurred by the act of God, and damages caused by misuse, abuse, and unauthorized modification.

3. Limited of Liability

LDS will not be held liable for incidental or consequential losses or damages to any act of God.

4. Reminder

Service requirement shall be subject to the presentation of this warrant card and defective parts to the manufacture LDS.

The warranty card will not be reissued if lost.

Product : KEYPAD ELECTRONIC KNOB & LEVER LOCK


Purchase Date :

Name & Address of Distributor :

LOCKEY DIGITAL SYSTEMS INC.
Mt. Pleasant Michigan (989) 773-2363
www.lockeyusa.com



E-DIGITAL ELECTRONIC LOCK SERIES




USER MANUAL




Attention : Do not use power tools

KEYPAD ELECTRONIC LEVER & KNOB INSTALLATION INSTRUCTION




The BACKSET is the distance between the center of cross bore and edge bore of the door. Adjustable latch fits both BACKSET of 2-3/8" (60mm) and 2-3/4" (70mm). Please follow the steps shown below for BACKSET adjustment.

- The backset shown on the left is 60mm (2-3/8").
 - Pull the cam toward right to extend the backset to 70mm (2-3/4").
 - The backset shown in figure C is 70mm (2-3/4"). Pulling the cam back to left will return the backset to 60mm (2-3/8").
- Note : The shape of cam should be square.




1. Mark The Door With Template



Select the height and backset as desired on the door face ; use the TEMPLATE as an indication to mark the center of the circle on the door face and the center of the door edge.

2. Drill Holes




Using the marks as a guide to drill a hole $\varnothing 2\text{-}1/8"$ (54mm) through the door face for the lockset, then a hole of $\varnothing 1"$ (25.4mm) for latch.


1

3. Identify Door Handing


Face the door from outside, the door is left handed if the hinge is on the left-hand side of the door, whereas the door is right handed if the hinge is on the right-hand side of the door.




4. Install Latch




- Insert the latch and lay the faceplate against the door edge. Use a pencil to mark it's perimeter, then take out the latch.



- Chisel out the portion you've marked with pencil to about 4mm (5/32") deep. Score the area within the borders as clearly and precisely as possible. Ensure the plate can fit flush with the door edge surface.




- Insert the latch and tighten it with screws. Be sure the holes for thru-bolts (next to the adjustable cam) are horizontally aligned.



- It is not necessary to chisel the door edge for the faceplate installation if you use a drive-in latch. (not incld) You may install it into the edge bore directly, making sure the bevel faces the outside assembly.

2


5. Install Strike




- Half-close the door to lay the latchbolt against the door frame. Mark the position of faceplate as an indication. Place the strike against the door frame and mark its perimeter. Be sure the center of strike is perfectly aligned with the center of faceplate.
- Drill a $\varnothing 25.4\text{mm}$ (1") hole with 13mm (1/2") depth on the center of strike outline. Then use the chisel to scrape out the door frame for 1.6mm (1/16") deep within your pencil mark. Ensure to chisel deep enough to allow the strike to lay flush with the frame surface.
- Insert the strike and tighten it with screws.
Note : please use "tapping screws" for metal door.

6. Install Keypad Assembly

- Place the leverset/knobset against keypad with tailpiece in vertical position inserted through cam of the latch.




- Pass the IC wire over the latch to the interior side of door.



3


7. Install Inside Mounting Plate

Pass the IC wire through the wire hole on the mounting plate and fix the mounting plate with screws. If outside lock assembly is lopsided, please loosen the screws to adjust its position and tighten the screws again.




8. Install Receiver Module

- Remove the battery cover (push it up and pull it out).
- Connect the IC wire and ensure the turn piece is horizontal, so that the tailpiece is able to engaged with the inside lever/knob. Then attach receiver module to the door with screws. It's optional to use the attached wood screw.
(Wood screw only for wood door)




- Insert 4 (AA) 1.5V alkaline batteries and put the battery cover back to the receiver module.





4

9. Change Lever Handing

- a. Be sure the levers are unlocked.
Insert the provided pin wrench into the small hole on the neck of lever and apply pressure to depress the catch and pull out the lever from the stem.
Follow the same steps to remove interior lever and exchange the position of inside and outside levers.



- b. Remove the cylinder from lever and insert it into opposite lever.
Then install the levers and make sure the small hole on the neck of lever aligns over the catch perfectly. Rotate the levers to see if it operates well.



① Programming Button

Programming Button is for entering codes, clearing errors and setting function.
It's also a lock button.

② Number Buttons

Input the user codes, each user code is 4-10 digits in length.

③ Cylinder

Lock/Unlock the lockset from exterior.

④ Gasket

Prevent water permeating into lockset.

⑤ Battery Lid

Slide the lid to change the batteries.

⑥ Battery Holder

Four AA (1.5V) Alkaline batteries.

⑦ R Button (Reset)

Restore default setting.

⑧ Turn-Button

Lock/Unlock the lockset from interior.

Specification / Function

1.Power

6V, four AA (1.5 v) Alkaline batteries.

2. Low Battery

- 2-1 The batteries should be changed immediately once you see button1 flashing in red and hear 10 rapid beep sounds when pressing programming button.
- 2-2 All settings are retained in the memory and will not be affected even if the battery is completely dead.
- 2-3 The lock still can be operated by key even there with a power outage.

3.Illuminated Indicator

- 3-1 Button1 flashes in green once when successful operation.
- 3-2 Button1 flashes in green twice when successful programming.
- 3-3 Button1 flashes in red 3 times when there is an operation error.
- 3-4 Button1 flashes in red 5 times with code input error, the system will shut down for system protection (Refer to 17).
- 3-5 Button1 flashes in orange 3 times when system has been restored to default setting.
- 3-6 Button1 flashes in orange slowly while in programming mode.

4.Audible Indicator

- 4-1 1 beep sound indicates a successful operation.
- 4-2 2 long beeps indicate successful programming
- 4-3 3 beeps indicate an operation error.
- 4-4 3 long beeps indicate that the system has been restored to default setting.
- 4-5 5 beeps with code input error, the system will shut down for system protection. (Refer to 17)
- 4-6 10 rapid beeps indicate the battery is low.

5.Programming Code

- 5-1 The preset Programming Code is 0000. Please change it into a new one during first operation.
- 5-2 Only one Programming Code for function setting.
- 5-3 Programming Code is only for function setting, you can't unlock the lockset by entering Programming Code.
- 5-4 Programming Code is 4-10 digits in length.
- 5-5 Programming Code can be changed anytime if needed.

6.User Code

- 6-1 The preset User Code is 1234. Please delete it and create a new one during first operation.
- 6-2 Up to 6 sets of User Codes can be saved.
- 6-3 User Code is only for unlocking the lock, without programming function.
- 6-4 User Code is 4-10 digits in length.
- 6-5 User Code can be deleted or added anytime if needed.

7.Delete Individual User Code

- 7-1 User Codes can be deleted individually. You can re-set the same number as code even if it's been deleted before.
- 7-2 Programming Code is needed when deleting individual User Code.

8.Delete All User Codes At Once

- 8-1 All the User Codes can be deleted at once. You can still reset the same numbers as codes even if they're deleted before.
- 8-2 Auto-locking and Keypad locking function will be invalid after deleting all User Codes and the lock can only be operated by key. These functions will be restored with new User Codes.
- 8-3 Programming Code is needed when deleting all User Codes.

9.Temporarily Disable All User Codes

- 9-1 Auto-locking and Keypad locking function will be invalid when User Codes are temporarily disabled. The lock can only be operated by key during this time.
- 9-2 Repeat the programming steps again to restore the auto-locking, keypad locking function and User Codes.

10.Create a Disposable User Code

- 10-1 Disposable User Code is no longer valid once it has been used.
- 10-2 You can reset same number as Disposal User Code again.
- 10-3 Programming Code is needed when creating a Disposable User Code.

11.Restore Preset Factory Code

- 11-1 You can restore Preset Factory Code by pressing "R" button on the interior receiver module when you forget Programming Code or you want to cancel all previous setting.
- 11-2 After restore, the Programming Code would be 0000; the User Code would be 1234 again.

12.Unlock the lockset

The lockset will be unlocked by key or pressing the User Code on keypad from the outside or by the interior turn-button.

13.Lock the lockset

The lockset will be locked by key or by pressing the Programming Button on keypad from the outside or by the interior turn-button.

14.To Activate / Deactivate Auto-Locking Function

14-1 The lockset will automatically lock itself within 10~99 seconds when this function is programmed.

14-2 This function is not preset at the beginning; it can be set if needed.

14-3 The preset delay-time is 30 seconds; you can adjust the period as you want.

14-4 Please repeat the same programming steps to cancel Auto-Locking function when needed.

15.Toggle Mute On/Off

15-1 You will hear beep sounds when pressing keypad, programming or operating errors. It can be turned off if needed.

15-2 LED Illumination is still functioning when it's in mute. As there will be no warning alarm, we suggest not to mute the beeper if it's not necessary.

15-3 Motor operating sound cannot be muted.

16.Code Protection Function

The system will shut down if entering unauthorized codes over 5 times.

The System will be operational again after 45 sec.

17.Illumination

The LED Keypad will light up when pressing any button for ease of operating in the dark.

Pass Code & Function Set up

1. The Lockset must be in the unlocked position while programming.
2. Change default Programming Code (0000) and User Code (1234) before function set up.
3. LED flashes orange slowly while programming. LED flashes green twice with 2 long beeps when input is correct. LED flashes red 3 times with 3 beeps when incorrect. (You need to wait for 6 seconds or press programming button when incorrect input is entered, then the system will be operational again.)
4. Each programming step should be done within 6 seconds.
5. You can lock/unlock this product with either the key or keypad.
Please refer to the following programming table for function set up.

Remark

1. We recommend to use alkaline batteries in order to stabilize the power supply.
2. Do not mix alkaline batteries with regular zinc-carbon ones or mixed brands.
3. Do not use any chemical liquid or lubricating oil with additives to clean the lock body, it will damage the surface or mainboard.
4. If there is any problem with the product, please contact LDS.

Function Programming

Programming Code (PC)
USER Code (UC)

Add New User Code



Remark :
Up to 6 sets of User Codes can be saved. User Code should be 4-10 digits in length.

Delete An Existing User Code



Delete All User Codes At once



Remark : Auto-locking and Keypad locking function will be disabled when User Codes are deleted. The lock can only be operated by the key during this time.

Change Programming Code



Toggle Autolock On/Off



Remark : The preset delay-time is 30 seconds, you can change the time by following the instructions below.
Repeat the steps to cancel the Auto-locking function.

Set Autolock Time Delay



Remark : 10-99 seconds delay-time available.

Programming Code (PC)
USER Code (UC)

Toggle Mute On/Off



Remark : Repeat same steps to turn sound On/Off.
LED illumination is still functioning when it's in mute, but there will be no warning alarm.

Enable/Disable All User Code



Remark : Auto-locking and Keypad locking function will not work when User Codes are disabled. The lock can only be operated with the key during this time.
Repeat the steps to enable the User Codes again.

Create a disposable User Codes



Remark : Disposable user code is no longer valid once it's been used.

Restore all preset lock settings

Press **R**

Remark : Press "R" button for over 5 seconds, the programming will be complete after you hear 3 long beeps.